W730

WOOD - SADDLE BACK

Contemporary molded back on solid wood frame.



SEAT

½" padded upholstered, contoured seat

BACK & FRAME

Full joinery, factory sealed construction European beech wood, with tan, nail-in nylon glides

QUICK SHIP CONFIGURATION

Seat - Vinyl & Frame



DIMENSIONS AND WEIGHTS

Chair (18) 31" 18" 16" 16" 13 lbs

W740

WOOD - VENEER MOLDED BACK & SEAT

Contemporary molded veneer back seat on a stylized hardwood frame.



SEAT & BACK

½" veneer molded

FRAME

Full joinery, factory sealed construction European beech wood, with tan, nail-in nylon glides

QUICK SHIP CONFIGURATION

Back & Frame



DIMENSIONS AND WEIGHTS

Chair (18) 32" 18" 19" 16.5" 13 lbs