



FLOOR MOP SINK INSTALLATION INSTRUCTIONS

MODEL MS-2424

INCLUDED CONTENTS

Mop Sink



(4) 3/8" Bolts



Strainer



STRAINER ASSEMBLY

Flat Strainer




Soft coupling
nut washer



Hard coupling
nut washer



Hard flange
nut washer



Flange washer



Drain locknut



FEATURES

- 24" x 24" x 13" overall
- 21" x 21" x 9" bowl
- 18 gauge stainless steel
- 2" drain included
- Mounting hardware included

INSTRUCTIONS

1. Sit unit on floor and align to 2-1/4" drain pipe (Pre-Installed and raised 3-1/2" from floor), drill four 3/8" holes by marking at factory punched holes on unit's feet.
2. Tighten all four 3/8" bolts and install strainer as shown above. Use a screwdriver to tighten driver bar, then remove driver bar and keep it in a safe place for future use.

