

<u>MACHINE#</u>	<u>WHAT IT MAKES</u>	<u>WHAT IT CAN BE CONVERTED TO</u>	<u>BLADE ASSEMBLY</u>	<u>PUSH BLOCK OR ASSEMBLY</u>
-----------------	----------------------	------------------------------------	-----------------------	-------------------------------

EASY WEDGER™ AND EASY APPLE CORER™

55550-4	4 SECTION WEDGE	Can be converted to any other machine in this series by changing the blade assy and push block.	428-4	55434
55550-6	6 SECTION WEDGE	Can be converted to any other machine in this series by changing the blade assy and push block.	428-6	55440
55550-8	8 SECTION WEDGE	Can be converted to any other machine in this series by changing the blade assy and push block.	428-8	55434
55550-10	10 SECTION WEDGE	Can be converted to any other machine in this series by changing the blade assy and push block.	428-10	55434-10
55550-8C	8 SECTION CORER & WEDGER	Can be converted to any other machine in this series by changing the blade assy and push block.	490-8	55447-8 (ALSO REQUIRES CORE PIN # 55448)