

WARING COMMERCIAL Ellipse™

BLENDING SYSTEM

QSG
Quick Start Guide



SCAN TO WATCH:
HOW TO ASSEMBLE YOUR WARING ELLIPSE™



WARING COMMERCIAL Ellipse™



THE FUTURE OF BLENDING HAS ARRIVED, AND IT'S ABOUT TIME! Experience the power of top-down blending that propels you beyond the limits of physics. The brand-new Waring Ellipse™ blending solution has been designed to change the way you think of blending with shorter cycles, greater output, and more consistent results.

Designed to take on every blending task with optimal efficiency, the Waring Ellipse™ revolutionizes blending. With a dual-motor system that maximizes speed and power to let you serve more customers in less time, the Waring Ellipse™ blends any product quickly. Don't let ingredients, time, manpower, or equipment limit you any longer! With the Waring Ellipse™, you're now free to go beyond traditional blending, and your customers will thank you!

WHAT'S IN THE BOX?



**BASE
MXEBU**



**DOCKING STATION
MXEDS1**



**SOUND ENCLOSURE
SE1500**



**LID
CAC193**



**JAR
CAC188**



**DRIVE
MXEDR**



**SINGLE
CHARGING STATION
MXECHG1**



**DASHER
CAC192**



IF YOU ARE MISSING ANY PARTS CALL 1-800-492-7464.
VISIT WWW.WARINGCOMMERCIALPRODUCTS.COM



QUICK START GUIDE



1 Place the Waring Ellipse™ docking station under the ellipse base.



2 Place your Waring Ellipse™ drive on the provided charging station and fully charge before first use.



3 Attach the sound enclosure to the Waring Ellipse™ base.



4 Attach dasher to the lid and place on the jar, then place the fully assembled jar on the Waring Ellipse™ base.





5 Turn the drive on by pressing the auto start button for 3 seconds. Once activated, remove the drive from the charging station and place it on the jar.



6 Close the sound enclosure and select blend program to begin blending.


HOW TO PROGRAM YOUR ELLIPSE BLENDER

1

To enter new program, press both  and  buttons simultaneously.







2

Press the program button you wish to set (pick 1-4). In this case, press .



3

Press  or  button to set speed value. Set to 65%. Once desired speed is reached, press  button to select speed.





4

NOTE: Time starts at 5 seconds.




5

Use  and  buttons to set time value (up to 90 seconds). Set to 7 seconds.







6

Press  button to confirm time setting.






7

Press  or  button to set speed value. Set to 100%. Once desired speed is reached, press  button to select speed. **NOTE:** Time starts at 5 seconds.



8

Use  and  buttons to set time value (up to 90 seconds). Set to 5 seconds. Press  button to confirm time setting.





9

To save the program setting, wait 5 seconds.



10

Press both  and  simultaneously.



waringcommercialproducts.com



@waringcommercial