



Platter (Winged)
R457 387 (15" x 10 3/4" / 38.1 cm x 27.3 cm), 6 ea



Platters (Rectangle Rim)
R457 359 (11 3/8" x 7" / 29 cm x 17.8 cm), 1 doz.
R457 384 (14 1/2" x 7" / 36.8 cm x 27.3 cm), 1 doz.



Platters
R457 367 (12 1/2" x 9 1/4" / 31.8 cm x 23.5 cm), 1 doz.
R457 383 (14 1/2" x 10 3/4" / 36.8 cm x 27.3 cm), 1 doz.



Platter (Rectangle)
R457 371S (13 1/2" x 10" / 34.3 cm x 25.4 cm), 1 doz.



A.D. Cup
R457 525 (2 3/4" / 7 cm), 3 doz.
3 1/2 oz. / 10.4 cl



A.D. Saucer (Fits 525)
R457 505 (4 1/8" / 10.3 cm), 3 doz.



Cup (Stackable)
R457 531 (3 1/4" / 8.2 cm), 3 doz.
9 oz. / 26.6 cl



Cup (Tall)
R457 512 (3 3/4" / 9.5 cm), 3 doz.
9 1/2 oz. / 28.1 cl



Saucer (512 & 531)
R457 500 (6" / 15.2 cm), 3 doz.



Mug (Stackable)
R457 572 (3 3/8" / 8.5 cm), 3 doz.
12 oz. / 35.5 cl



Mug
R457 563 (4 7/8" / 12.4 cm), 3 doz.
13 oz. / 38.4 cl



Creamer
R457 804 (3" / 7.6 cm), 3 doz.
6 oz. / 17.7 cl



Sugar Packet
R457 906 (3 3/4" x 2 3/4" / X cm x X cm), 3 doz.



Plate Cover (Square) (Fits 136S)
J0143030A (8 1/2" / 21.6 cm)
Plate Cover (Square) (Fits 147S)
J0143030B (10" / 25.1 cm)



Plate Cover (Rectangle) (Fits 359)
J0093061A (11 3/8" x 7" / 28.7 cm x 17.8 cm)



5 Crown Cover (Round)
(Fits 154, 155, 156, 157, 786, 795)
J0093041AQC (12 5/8" / 32.5 cm)

Platter Cover (Rectangle) (Fits 384)
J0093061B (14 1/2" x 7" / 36.8 cm x 12.7 cm)